



MICROTEC®

M197 Ducati Engine Control

Software version Professional 1.2b

Rev 1.01

MICROTEC S.R.L.

Via Avris 3
21032 Caravate (VA)
ITALY

Tel – 0332601731
Fax – 0332771777
Email – info@microtec.cc
Web – www.microtec.cc

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

General

After installation your software should look like this starting it.



The MonM197 v1.2 splits the ECU settings into 2 distinct areas:

- **Config** (pink)– section to set the bike model, the setting of the sensor and the dashboard installed on the bike.
- **Map** (yellow)– Any parameters that could be considered as an Engine tuning settings.

If your system has been pre-designed or you have been given some base settings to work with, you can load them now using the LOAD buttons at the bottom of this page.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Save / Load / Transmit


Any changes that are made to software parameters must be saved and then transmitted (uploaded) to the ECU for them to take affect.




Save - Use the Save button on the tool bar to save any changes you have made, you will be given the choice to save either the Configuration or the Map file, if you have made changes to both of these zones you will need to make the Save file to both the configuration file (*.ecd) and the Map file (*.emd)

Your choice of file name is completely free.

You will also notice that the file names shown above the button bar will change to match your naming choice. These are the file names in use on your PC, NOT the ones currently loaded in the ECU.



Load - Use the Load button to choose a previously stored Configuration or Map file. After pressing you are again given the choice to load either the Config or Map as shown above.




Transmit – To transmit (upload) a file from your PC to the ECU you must first establish a link by pressing the Open button, if the link is established correctly the TX and RX button will become active as shown here.

To send either a Configuration or a Map to the ECU press the **TX** button, the following window will open.

By pressing the **Configuration** button you will send the complete Configuration file to the ECU, this takes approx 5-6 seconds and will be followed by this confirmation.



By pressing **Mapping 1** or **Mapping 2** you can send your complete map into either Map position 1 or Map position 2. In this way you can have 2 completely different maps that are instantly switch able by the rider/driver with start button.



By default the Map 1 is used when the switch input is open circuit.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Upload





Receive (RX) – To receive (download) a file from your ECU to the PC you must first establish a link by pressing the Open button to active the RX button.

When the Rx button is pressed you can choose to download the Configuration, Map 1 or Map 2. make the selection using this window.

Whenever you download a file from the ECU, it is taken in as a single complete file containing all of the parameters within that zone. (zone being either the Config or the map). If the process is completed without error you will see this message.


You should also note that the file name showing above the button bar would now represent the name of the file taken from the ECU.



MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

The **config** page can be found by pressing this button



Mon197 Professional v1.2b

Configuration (general)

Engine

Bike: Superbike 1098
 Engine Type: 2cyl Ducati
 Toothed Wheel Arrangement: 48 - 2
 Coupling Angle (Smot0->TDC1) [deg]: 330.0
 Trigger: Inductive

Idling Control

Kp: 8.00
 Ki: 0.0000
 Kd: 8.000

Dash Title (max 15 char): *MICROTEC*

Signal Type

Starter	Active Low
Stop	Active Low
Clutch	Active Low
Side Stand	Active Low
Neutral	Active Low
Shift Set	Active Low
OFF Drop Switch	Active Low
Key Lock	Active Low
Low Oil Pressure	Active Low

Injection Battery Offset

[Volt]	7.0	8.0	9.0	10.0	10.5	11.0	11.5	12.0	12.5	13.0	13.5	14.0	14.5	15.0	16.0	17.0
Std [ms]	1.200	1.076	0.899	0.706	0.694	0.546	0.497	0.449	0.385	0.321	0.297	0.273	0.240	0.208	0.144	0.144

Dwell

[Volt]	7.0	8.0	9.0	10.0	10.5	11.0	11.5	12.0	12.5	13.0	13.5	14.0	14.5	15.0	16.0	17.0
[ms]	3.800	3.800	3.800	3.800	3.580	2.760	2.440	2.340	2.160	2.040	1.840	1.740	1.640	1.520	1.520	1.520

PickUp Table

RPM	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500
[deg]	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Notes

1098 configuration

USB: 1098s_fw102, 1098s_fw102_SP_SO_v01, M197 v1.2

Close Tx Rx Config Linear Maps Inj Adv Param Save Load Monitor Diag Code Pwd Info Exit

In this window it's possible to select the type of bike, which will be installed on the ecu(**Engine – Bike**). This selection will automatically force a number of windows. The only editable are:

Customizable dashboard welcome message through this window.

Dash Title (max 15 char)

MICROTEC

Signal Type

OFF Drop Switch Active Low

In this part you can activate fallino sensor (**drop switch on**) and his logical state of operation:
 If active with ground contact select **active low**
 If active with 12V contact select **active high**.

Idling control – section about control proportional, integrative, and derivative control valve for the management of the minimum (P.I.D.) It's recommended not change these values so as not to compromise the stability of the valve

Idling Control

Kp: 8.00
 Ki: 0.0000
 Kd: 8.000

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
 Tel. +39 0332 601731 – Fax +39 0332 771777

Configuration - General – Injection battery offset

Injection Battery Offset																
[Volt]	7.0	8.0	9.0	10.0	10.5	11.0	11.5	12.0	12.5	13.0	13.5	14.0	14.5	15.0	16.0	17.0
Std [ms]	1.200	1.076	0.899	0.706	0.694	0.546	0.497	0.449	0.385	0.321	0.297	0.273	0.240	0.208	0.144	0.144
Aux [ms]	1.547	1.289	1.261	1.155	1.057	0.959	0.851	0.759	0.689	0.635	0.589	0.537	0.505	0.469	0.469	0.469

This table is of significant importance for the system to calculate the injection time. At different battery voltage levels the injector will take a specific time is 'Ms' (milli seconds) to go from fully closed when the signal is received to fully open. The lower the voltage the longer this will take, but there is course fuel being injected during this phase.

You are free to choose your own 'break point' within the top row and differing offset values for the upper and lower injector bank. Note: This data is sometimes referred to as injector 'dead time'

These additive corrections are referred to as **Std** and **Aux** for standard bank and auxiliary bank (double injection).

Configuration - General – Dwell

Dwell																
[Volt]	7.0	7.5	8.0	8.5	9.0	9.5	10.0	10.5	11.0	11.5	12.0	12.5	13.0	14.0	15.0	16.0
[ms]	7.999	7.999	7.999	6.007	4.851	3.727	3.148	2.731	2.506	2.281	2.088	1.928	1.831	1.606	1.446	1.317

This table controls the duration of the ignition coil 'trigger' pulse as a function of battery voltage in Ms (milli seconds). You are free to choose your own 'breakpoints' within the top row.

Configuration - General – Pick up

Pick-Up Table																
RPM	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
[deg]	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

This table contains the correction to spark advance at differing RPM values (applied to all cylinders) to correct for errors resulting from the signal delay from the crank pick up.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Can – acquisition

Mon197 Professional v1.2b

Configuration (CAN-acquisition)

Frame	ID (hex)	Frequency	Channel 1	Channel 2	Channel 3	Channel 4
1	200	200 Hz	RPM	Mean RPM	-	Milliseconds
2	204	200 Hz	Revolutions	Smot Errors	-	Gap Errors
3	208	200 Hz	Throttle	Lambda NBego 1	Lambda NBego 2	-
4	20C	200 Hz	Advance 1	Advance 2	Terog Base 1	Terog Base 2
5	210	200 Hz	Terog 1A	Terog 2A	Terog 1B	Terog 2B
6	214	200 Hz	TetaBase	Phase	FaseBase	PickUp Table
7	218	200 Hz	KJbnc 1	KJbnc 2	KAbnc 1	KAbnc 2
8	21C	200 Hz	KJbnc	KAbnc	KFbnc	-
9	220	200 Hz	Adv Transient	Inj Transient	OffsVbatA	OffsVbatB
10	224	200 Hz	KJuser 1	KJuser 2	KAuser 1	KAuser 2
11	228	200 Hz	DJDInT	DADInT	DJDInTrpm	DJDInTh2o/oil
12	22C	200 Hz	KJTair	KATair	KJTH2O/OIL	KATH2O/OIL
13	230	200 Hz	KJVel	KAVel	KJPbaro	KAPbaro
14	234	200 Hz	KJCocA	KJCocB	-	KJCrank
15	238	200 Hz	Air T	Water/oil T	-	Air Baro P
16	23C	200 Hz	Dwell	Battery	Idl Set-Point	Idl Step
17	240	200 Hz	Engine,DINs	DOUts,Status	Shift,Inj.Err.	Reset
18	244	200 Hz	Map-Tune Count	Map-Tune Flags	CAN lambda 1	CAN lambda 2
19	248	200 Hz	Velocity	Space	-	-
20	24C	200 Hz	-	-	-	-

USB 1098s_fw102 1098s_fw102_SP_SO_v01 M197 v1.2

Close Tx Rx Config Linear Maps Inj Adv Param Save Load Monitor Diag Code Pwd Info Exit

With a second press on **config** button you can see this window. This page only show address and trasmission frequency of CAN channels transmit from ECU. You can see also the name of the signal. These channels are utilized with an acquisition data to recording all these values.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Linear

The **Linear** page can be found by pressing this button



The screenshot shows the 'Linearizations' page in the Mon197 Professional v1.2b software. The page has a blue title bar and a blue border. The main content area is white. At the top, there is a blue bar with the text 'Mon197 Professional v1.2b' and three window control buttons (minimize, maximize, close). Below this, the title 'Linearizations' is displayed in a blue font. The page contains three tables, each with a title bar and a data grid. The first table is titled 'Throttle' and has a button labeled 'Interpolate...'. The second table is titled 'Water Temperature'. The third table is titled 'Lambda Narrow-Band 1'. Below it is another table titled 'Lambda Narrow-Band 2'. At the bottom of the page, there is a status bar with the text 'USB', '1098s_fw102', '1098s_fw102_SP_SO_v01', 'M197 v1.2', and a row of buttons: Close, Tx, Rx, Config, Linear, Maps, Inj, Adv, Param, Save, Load, Monitor, Diag, Code, Pwd, Info, Exit. The 'Linear' button is highlighted in blue.

Throttle																	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
A/D	55	109	164	218	272	326	381	435	489	543	598	652	706	760	815	869	
[deg]	2.5	8.1	13.6	19.2	24.8	30.3	35.9	41.5	47.0	52.6	58.2	63.7	69.3	74.9	80.4	86.0	

Water Temperature																	
A/D	183	251	310	378	456	541	628	713	791	857	885	910	949	977	996	1008	
[°C]	125.0	110.0	100.0	90.0	80.0	70.0	60.0	50.0	40.0	30.0	25.0	20.0	10.0	0.0	-10.0	-20.0	

Lambda Narrow-Band 1																	
A/D	50	50	50	50	50	50	225	235	570	580	950	950	950	950	950	950	
L	15.4	15.4	15.4	15.4	15.4	15.4	14.9	14.7	14.7	14.5	14.0	14.0	14.0	14.0	14.0	14.0	

Lambda Narrow-Band 2																	
A/D	50	50	50	50	50	50	225	235	570	580	950	950	950	950	950	950	
L	15.4	15.4	15.4	15.4	15.4	15.4	14.9	14.7	14.7	14.5	14.0	14.0	14.0	14.0	14.0	14.0	

This page will vary depending on the bike model selected in the configuration page.

You can linearise the different linear sensor such gas, water temperature, air temperature, oil temperature, two narrow band and barometric pressure.

Throttle – To calibrate the throttle sensor, first choose the values for the break points. Use the Monitor page to note the minimum and maximum value for the throttle inputs and enter these values at the 2 ringed positions. Now press Interpolate and the software will automatically re-distribute the A/D values equally between these 2 extremes.

In all cases you are free to enter your own values for the breakpoints and the A/D representation.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps - edit

The **Maps** page can be found by pressing this button



In this section you can make changes to the original map about injection and advance. You can also view the listed plans in 2D and 3D graph

Maps edit Reset Selection

Injection: ▼ Cyl. 1 **Multiple Map** RPM

	200	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500	
✓ Injection	2.270	2.214	2.206	2.177	2.096	2.065	1.866	1.774	1.700	1.590	1.537	1.503	1.485	1.548	1	
Advance	2.424	2.421	2.409	2.396	2.383	2.370	2.357	2.345	2.332	2.319	2.306	2.293	2.280	2.268	2	
Injection Correction by Velocity	2.544	2.541	2.526	2.512	2.497	2.482	2.467	2.453	2.438	2.423	2.408	2.394	2.379	2.364	2	
Advance Correction by Velocity	2.664	2.661	2.644	2.627	2.611	2.594	2.577	2.561	2.544	2.527	2.510	2.494	2.477	2.460	2	
Cranking Correction																
4.0	3.599	3.568	3.521	2.784	2.780	2.762	2.743	2.724	2.706	2.687	2.668	2.650	2.631	2.613	2.594	2
5.0	3.852	3.852	3.852	3.024	3.019	2.997	2.974	2.952	2.929	2.907	2.884	2.862	2.839	2.817	2.794	2
6.0	3.852	3.852	3.852	3.264	3.259	3.232	3.206	3.180	3.153	3.127	3.100	3.074	3.048	3.021	2.995	2
7.0	3.884	3.884	3.884	3.504	3.498	3.468	3.437	3.407	3.377	3.347	3.316	3.286	3.256	3.225	3.195	3
8.0	4.057	4.057	4.057	3.744	3.737	3.703	3.669	3.635	3.601	3.566	3.532	3.498	3.464	3.430	3.396	3
10.0	4.195	4.179	4.164	4.148	4.140	4.102	4.063	4.024	3.985	3.946	3.907	3.868	3.829	3.790	3.751	3
12.0	4.483	4.466	4.450	4.433	4.424	4.383	4.341	4.300	4.258	4.216	4.174	4.139	4.144	4.150	4.043	3
15.0	4.916	4.897	4.880	4.861	4.851	4.806	4.759	4.713	4.667	4.620	4.575	4.545	4.615	4.690	4.481	4
20.0	5.637	5.616	5.595	5.573	5.562	5.509	5.455	5.402	5.349	5.295	5.242	5.222	5.402	5.589	5.212	4
25.0	6.540	6.687	6.579	6.569	6.579	6.579	6.687	6.620	6.579	6.415	6.201	6.182	5.925	6.038	6.024	5
30.0	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	7.020	5
35.0	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	6
40.0	7.209	7.209	7.188	7.188	7.190	7.199	7.209	7.209	7.188	7.188	7.190	7.199	7.209	7.209	7.188	7
50.0	7.177	7.132	7.132	7.132	7.158	7.291	7.177	7.132	7.132	7.132	7.158	7.291	7.177	7.132	7.132	7
65.0	7.415	7.364	7.364	7.136	7.152	7.236	7.415	7.364	7.364	7.136	7.152	7.236	7.415	7.364	7.364	7
90.0	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7.357	7

Notes: 1098s - Standard exhaust + slip ons

Graph: 2D 3D

Tuning: AUTO MANUAL

Using the drop-down menu on the right you can select if work on the listed plans listed injection or advance.

Breakpoint of throttle and rpm can be edited to your liking, the only constraint is that cylinder 1 and 2 have the same breakpoint.

Through these two button you can choose to work on the cylinder 1 or 2 (**cyl 1** **e cyl 2**) or unify its by pressing **Multiple map**.



Using these buttons you access to the tuning mode, manual and automatic. To get out from one of two modes, click on maps. These two functions are explained below.

As long as the data will not be saved will appear in the cells colored red to identify files that have changed.

0.0	19.1	40.0
0.0	19.1	40.0
0.0	19.1	40.0


MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Edit / Injection

Choose Injection from the pull down menu to display a table of fuel injector Ms plotted against RPM / Throttle

Changes to individual cells can be made by 'double clicking' and typing directly into the cell the new value.



Use the mouse to drag an area covering multiple cells as shown here, then press the right mouse button to open the Edit window.

		Injection				Cyl. 1
		[ms]	900	1000	1100	1200
Throttle	2.0	2.521	2.573	2.472	2.270	
	2.5	2.568	2.673	2.525	2.424	
	3.0	3.220	3.268	3.224	2.544	
	3.5	3.553	3.505	3.441	2.664	
	4.0	3.599	3.568	3.521	2.784	
	5.0	3.852	3.852	3.852	3.024	
	6.0	3.852	3.852	3.852	3.264	

All cylinders – Tick here if you want your changes to be applied to all cylinders, not just the one you are working on

Set – Applies a fixed value to all of the chosen cells

Add – Adds a fixed amount to all of the chosen cells

%Add – Adds a percentage to all of the chosen cells

Interpolate – Tick here to interpolate 9 or more cells


Interp. Rows – Tick here to interpolate 3 or more cells in the same row

Interp. Columns – Tick here to interpolate 3 or more cells in the same columns

Copy – Copies the selected cell values to all other cylinders in this group.

Maps / Edit / Advance

Choose Advance from the pull down menu to display a table of spark advance in Deg plotted against RPM / Throttle



Individual cylinder mapping is not available

Changes to individual cells can be made by 'double clicking' and typing directly into the cell the new value.

Use the mouse to drag an area covering multiple cells as shown here, then press the right mouse button to open the Edit window.

		Advance					RPM
		[deg]	1000	1500	2100	3000	4000
Throttle	1.4	-5.0	2.0	36.0	38.8	40.5	
	2.8	-5.0	2.0	35.0	39.8	42.5	
	4.9	-5.0	2.0	34.0	42.3	46.8	
	8.1	-5.0	2.0	29.3	38.0	46.8	
	10.9	-5.0	2.0	24.8	37.0	47.3	
	15.2	-5.0	2.0	21.8	31.5	40.0	

Set – Applies a fixed value to all of the chosen cells

Add – Adds a fixed amount to all of the chosen cells

%Add – Adds a percentage to all of the chosen cells

Interpolate – Tick here to interpolate 9 or more cells

Interp. Rows – Tick here to interpolate 3 or more cells in the same row


Interp. Columns – Tick here to interpolate 3 or more cells in the same columns

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Edit / Injection correction by Velocity

Injection correction percentage as a function of TPS/SPEED - **KJVel**



Changes to individual cells can be made by 'double clicking' and typing directly into the cell the new value.

Use the mouse to drag an area covering multiple cells as shown here, then press the right mouse button to open the Edit window.

Injection Correction by Velocity						Velocity
K						5
Throttle	1.4	1.000	1.000	1.000	1.000	1.000
	2.8	1.000	1.000	1.000	1.000	1.000
	4.9	1.000	1.000	1.000	1.000	1.000
	8.1	1.000	1.000	1.000	1.000	1.000
	10.9	1.000	1.000	1.000	1.000	1.000
	15.2	1.000	1.000	1.000	1.000	1.000

Set – Applies a fixed value to all of the chosen cells

Add – Adds a fixed amount to all of the chosen cells

%Add – Adds a percentage to all of the chosen cells

Interpolate – Tick here to interpolate 9 or more cells


Interp. Rows – Tick here to interpolate 3 or more cells in the same row

Interp. Columns – Tick here to interpolate 3 or more cells in the same columns

Copy - Copies the selected cell values to all other cylinders in this group.

Maps / Edit / Advance correction by Velocity

Injection correction additive as a function of TPS/SPEED - **KAVel**



Changes to individual cells can be made by 'double clicking' and typing directly into the cell the new value.

Use the mouse to drag an area covering multiple cells as shown here, then press the right mouse button to open the Edit window.

Advance Correction by Velocity						Velocity
[deg]						500
Throttle	1.4	0.0	0.0	0.0	0.0	0.0
	2.8	0.0	0.0	0.0	0.0	0.0
	4.9	0.0	0.0	0.0	0.0	0.0
	8.1	0.0	0.0	0.0	0.0	0.0
	10.9	0.0	0.0	0.0	0.0	0.0
	15.2	0.0	0.0	0.0	0.0	0.0

Set – Applies a fixed value to all of the chosen cells

Add – Adds a fixed amount to all of the chosen cells

%Add – Adds a percentage to all of the chosen cells

Interpolate – Tick here to interpolate 9 or more cells

Interp. Rows – Tick here to interpolate 3 or more cells in the same row

Interp. Columns – Tick here to interpolate 3 or more cells in the same columns

Copy - Copies the selected cell values to all other cylinders in this group.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Edit / Cranking corrections

This is the starting enrichment map **KJCrank** with the temperature at the left side and the number of crank rotations on the upper row. Within the table are the gains to be applied to the map during the start procedure.

To help understand this, choose a typical temperature at the left side (example +30°C) for the first 5 rotations of the engine the base fuel map will be multiplied by 2.01, from 5-10 rotations this will drop to 1.82 and onwards until the far right hand column is reached. The map will then work from this final cell downwards as the engine warms up and normal running temperature is reached.

Mon197 Professional v1.2b

Maps edit

Reset Selection

Injection [ms]	900	1000	1100	1200	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500
2.0	2.521	2.573	2.472	2.270	2.214	2.206	2.177	2.096	2.065	1.866	1.774	1.700	1.590	1.537	1.503	1.485	1.548	1
2.5	2.568	2.673	2.525	2.424	2.421	2.409	2.396	2.383	2.370	2.357	2.345	2.332	2.319	2.306	2.293	2.280	2.268	2
3.0	3.220	3.268	3.224	2.544	2.541	2.526	2.512	2.497	2.482	2.467	2.453	2.438	2.423	2.408	2.394	2.379	2.364	2
3.5	3.553	3.505	3.441	2.664	2.661	2.644	2.627	2.611	2.594	2.577	2.561	2.544	2.527	2.510	2.494	2.477	2.460	2
4.0	3.599	3.568	3.521	2.784	2.780	2.762	2.743	2.724	2.706	2.687	2.668	2.650	2.631	2.613	2.594	2.575	2.557	2
5.0	3.852	3.852	3.852	3.024	3.019	2.997	2.974	2.952	2.929	2.907	2.884	2.862	2.839	2.817	2.794	2.772	2.749	2
6.0	3.852	3.852	3.852	3.264	3.259	3.232	3.206	3.180	3.153	3.127	3.100	3.074	3.048	3.021	2.995	2.968	2.942	2
7.0	3.884	3.884	3.884	3.504	3.498	3.468	3.437	3.407	3.377	3.347	3.316	3.286	3.256	3.225	3.195	3.165	3.135	3
8.0	4.057	4.057	4.057	3.744	3.737	3.703	3.669	3.635	3.601	3.566	3.532	3.498	3.464	3.430	3.396	3.361	3.327	3
10.0	4.195	4.179	4.164	4.148	4.140	4.102	4.063	4.024	3.985	3.946	3.907	3.868	3.829	3.790	3.751	3.712	3.673	3
12.0	4.483	4.466	4.450	4.433	4.424	4.383	4.341	4.300	4.258	4.216	4.174	4.139	4.144	4.150	4.043	4.023	3.945	3
15.0	4.916	4.897	4.880	4.861	4.851	4.806	4.759	4.713	4.667	4.620	4.575	4.545	4.615	4.690	4.481	4.490	4.354	4
20.0	5.637	5.616	5.595	5.573	5.562	5.509	5.455	5.402	5.349	5.295	5.242	5.222	5.402	5.589	5.212	5.267	5.034	4
25.0	6.540	6.687	6.579	6.569	6.579	6.579	6.687	6.620	6.579	6.415	6.201	6.182	5.925	6.038	6.024	5.480	5.484	5
30.0	7.020	7.020	7.020	7.020	7.020	7.020	7.034	7.034	7.034	7.030	6.979	6.928	6.943	6.996	6.832	6.196	6.120	5
35.0	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.040	6.931	6.871	6.973	7.011	7.072	6.663	6.488	6
40.0	7.209	7.209	7.188	7.188	7.190	7.199	7.208	7.217	7.227	7.236	7.245	7.259	7.304	7.307	7.328	7.284	7.004	7
50.0	7.177	7.132	7.132	7.132	7.158	7.291	7.148	7.189	7.183	7.226	7.239	7.329	7.396	7.554	7.573	7.658	7.606	7
65.0	7.415	7.364	7.364	7.136	7.152	7.236	7.047	7.127	7.207	7.247	7.236	7.229	7.413	7.616	7.570	7.658	7.603	7
90.0	7.357	7.357	7.357	7.357	7.357	7.357	7.085	7.085	7.085	6.974	7.263	7.333	7.499	7.624	7.644	7.660	7.607	7

Notes

1098s - Standard exhaust + slip ons

Graph: 2D 3D

Tuning: AUTO MANUAL

USB 1098s_fw102 1098s_fw102_SP_SO_v01 M197 v1.2

Close Tx Rx Config Linear Maps Inj Adv Param Save Load Monitor Diag Code Pwd Info Exit

Edit Map

[%] 0.0

100.0 80.0 60.0 40.0 20.0 0.0 -20.0 -40.0 -60.0 -80.0 -100.0

☐ Set
☐ Add
☒ %Add
☐ Interpolate
☐ Interp. Rows
☐ Interp. Columns

Apply Cancel

Set – Applies a fixed value to all of the chosen cells

Add – Adds a fixed amount to all of the chosen cells

%Add – Adds a percentage to all of the chosen cells

Interpolate – Tick here to interpolate 9 or more cells

Interp. Rows – Tick here to interpolate 3 or more cells in the same row

Interp. Columns – Tick here to interpolate 3 or more cells in the same columns


MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

2D graph


Using the 2D button at the bottom of the page you access to the window of the graph in two dimensions.

Graph:	2D
	3D



In this window you can change the values of correction also to see the curve. A multi selection of points is possible by pressing and dragging the right mouse button. You can also change from one cylinder to another by pressing the button **Cyl. 1**

3D graph



Graph 3D show with more immediate view all the corrections applied and their homogeneity. Graph reachable through 3D button.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Mapping overview

Mon197 Professional v1.2b

Maps tuning manual Tuning OFF Manual Off

Injection Cyl. 1 RPM Cylinder 1 Lambda 1 - Cylinder 2 Lambda 2

[ms]	900	1000	1100	1200	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500
2.0	2.521	2.573	2.472	2.270	2.214	2.206	2.177	2.096	2.065	1.866	1.774	1.700	1.590	1.537	1.503	1.485	1.548	1
2.5	2.568	2.673	2.525	2.424	2.421	2.409	2.396	2.383	2.370	2.357	2.345	2.332	2.319	2.306	2.293	2.280	2.268	2
3.0	3.220	3.268	3.224	2.544	2.541	2.526	2.512	2.497	2.482	2.467	2.453	2.438	2.423	2.408	2.394	2.379	2.364	2
3.5	3.553	3.505	3.441	2.664	2.661	2.644	2.627	2.611	2.594	2.577	2.561	2.544	2.527	2.510	2.494	2.477	2.460	2
4.0	3.599	3.568	3.521	2.784	2.780	2.762	2.743	2.724	2.706	2.687	2.668	2.650	2.631	2.613	2.594	2.575	2.557	2
5.0	3.852	3.852	3.852	3.024	3.019	2.997	2.974	2.952	2.929	2.907	2.884	2.862	2.839	2.817	2.794	2.772	2.749	2
6.0	3.852	3.852	3.852	3.264	3.259	3.232	3.206	3.180	3.153	3.127	3.100	3.074	3.048	3.021	2.995	2.968	2.942	2
7.0	3.884	3.884	3.884	3.504	3.498	3.468	3.437	3.407	3.377	3.347	3.316	3.286	3.256	3.225	3.195	3.165	3.135	3
8.0	4.057	4.057	4.057	3.744	3.737	3.703	3.669	3.635	3.601	3.566	3.532	3.498	3.464	3.430	3.396	3.361	3.327	3
10.0	4.195	4.179	4.164	4.148	4.140	4.102	4.063	4.024	3.985	3.946	3.907	3.868	3.829	3.790	3.751	3.712	3.673	3
12.0	4.483	4.466	4.450	4.433	4.424	4.383	4.341	4.300	4.258	4.216	4.174	4.139	4.144	4.150	4.043	4.023	3.945	3
15.0	4.916	4.897	4.880	4.861	4.851	4.806	4.759	4.713	4.667	4.620	4.575	4.545	4.615	4.690	4.481	4.490	4.354	4
20.0	5.637	5.616	5.595	5.573	5.562	5.509	5.455	5.402	5.349	5.295	5.242	5.222	5.402	5.589	5.212	5.267	5.034	4
25.0	6.540	6.687	6.579	6.569	6.579	6.579	6.687	6.620	6.579	6.415	6.201	6.182	5.925	6.038	6.024	5.480	5.484	5
30.0	7.020	7.020	7.020	7.020	7.020	7.020	7.034	7.034	7.034	7.030	6.979	6.928	6.943	6.996	6.832	6.196	6.120	5
35.0	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.152	7.040	6.931	6.871	6.973	7.011	7.072	6.663	6.488	6
40.0	7.209	7.209	7.188	7.188	7.190	7.199	7.208	7.217	7.227	7.236	7.245	7.259	7.304	7.307	7.328	7.284	7.004	7
50.0	7.177	7.132	7.132	7.132	7.158	7.291	7.148	7.189	7.183	7.226	7.239	7.329	7.396	7.554	7.573	7.658	7.606	7
65.0	7.415	7.364	7.364	7.136	7.152	7.236	7.047	7.127	7.207	7.247	7.236	7.229	7.413	7.616	7.570	7.658	7.603	7
90.0	7.357	7.357	7.357	7.357	7.357	7.357	7.085	7.085	7.085	6.974	7.263	7.333	7.499	7.624	7.644	7.660	7.607	7

TH2O / OIL 70.0

Over-Rev

Cut-Off

Cranking

Transient

OverTime Inj

Save Load

Current Value

RPM 0

Throttle 12.8

Lambda 1 0.0

Lambda 2 0.0

Pause

For Help, press F1

Manual	Step	Current	Corrected	Correction	
Double Correction	Injection 1	0.010	4.598	4.598	1.000 Freeze
	Injection 2	0.010	4.598	4.598	1.000 Freeze
	Advance	0.5	6.0	6.0	0.0 Freeze

USB 1098s_fw102 1098s_fw102_SP_SO_v01 M197 v1.2

Close Tx Rx Config Linear Maps Inj Adv Param Save Load Monitor Diag Code Pwd Info Exit

This page gives you 2 options for mapping.

- Manual tuning where the operator uses the 'sliders' or numeric fields at the bottom of the page to define the values of spark advance and fuel at each cell.
- Auto tune – In this mode a fixed AFR value is used a target and the ECU will automatically adjust the fuel for you. You also have the opportunity to use Auto Tune both on the dyno and on the road.

The page displayed is the manual mode of the mapping.

Maps / Page function overview

For Help, press F1

TH2O / OIL 3.0

Over-Rev

Cut-Off

Cranking

Transient

OverTime Inj

Save Load

Current Value

RPM 0

Throttle 24.0

Lambda 1 0.0

Lambda 2 0.0

Pause

Manual	Step	Current	Corrected	Correction	
Double Correction	Injection 1	0.010	6.359	6.359	1.000 Freeze
	Injection 2	0.010	6.359	6.359	1.000 Freeze
	Advance	0.5	6.0	6.0	0.0 Freeze

RPM – value of engine RPM

Throttle – Value of Throttle sensor

Manual tuning / Injection / Current – Value of cell taken from the map

Manual tuning / Injection / Corrected – Value of injection time as a result of the manual adjustments.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Manual tuning / Advance / Current – Value of cell taken from the map

Manual tuning / Advance / Corrected – Value of advance as a result of the manual adjustments.

Freeze – Applies the adjustment to the specific cell within the ECU and then automatically returns to nil offset.

Lambda – Current value of the lambda sensor in AFR

Enabled – This LED lights when the 'lambda searching phase' of the tuning strategy is permitted (not considering the enable setting of single cells). The lambda searching phase is inhibited during cranking, gear change, injection transients, engine cut-off, when the water temperature exceeds the given limits, or when the engine speed is near the limit set in the "Parameters" page..

Cranking – LED turns from brown to red during engine start. When active mapping will be inhibited.

Over rev – LED turns from brown to red when the engine is within 150RPM of the limiter.

Cut off – LED turns from brown to red when the 'cut off' strategy is enabled. When active mapping will be inhibited.

Transient - LED turns from brown to red when the transient strategy is active. When active mapping will be inhibited.

OverTime inj – LED turns from brown to red when injector are in over time

TH2O – Value of water temperature.

Injection											Cyl. 1	RPM	Cylinder 1 Lambda 1 - Cylinder 2 Lambda 2	
[ms]														
Throttle	2.0	2.521	2.573	2.472	2.270	2.214	2.206	2.177	2.096	2.065	1.86		✓ Cylinder 1 Lambda 1 - Cylinder 2 Lambda 2	
	2.5	2.568	2.673	2.525	2.424	2.421	2.409	2.396	2.383	2.370	2.35		Cylinder 1 Lambda 1 - Cylinder 2 Lambda 1	
	3.0	3.220	3.268	3.224	2.544	2.541	2.526	2.512	2.497	2.482	2.46		Cylinder 1 Lambda 1 - Cylinder 2 Not Active	
	3.5	3.553	3.505	3.441	2.664	2.661	2.644	2.627	2.611	2.594	2.57		Cylinder 1 Not Active - Cylinder 2 Lambda 2	

Injection 1 – Use the pull down to visualize the map that you plan to work with

Cylinders – This option lets you choose to apply your mapping to all cylinders equally or to specific cylinders. Also through the different combinations you can choose how lambda probe work.

Maps / Manual mapping

Before you begin mapping it is important to make sure that you have transmitted the latest version of your configuration and 'start map' into map slot 1

1. Make sure that your external map switch is in position 1 (open circuit)
2. Run the engine and check that all sensor readings are correct.
3. Choose whether to map the injection on 'all cylinders' or an individual one
4. Use the left pull down to visualise the map you plan to work in.

To begin manual mapping press the **Manual** button at the top of the page. The PC will now read back from the ECU the latest version of the injection and spark map. At the top of the page you will see a series of messages.

- Synchronising mapping data
- Loading injection data
- Loading advance data
- Manual tuning mode (you are now ready to map)

You will notice that the file name you are now working with at the bottom of the screen is prefixed by a *, this is to indicate that the map has been taken from the ECU and not yet stored on your PC.

Adjust the engine using the dyno so that the throttle and RPM align with your chosen cell. Correct engine state will be indicated by the RPM and TPS values changing from yellow to red and the cell in the main window changing to grey as shown here.

10	4.030	3.743	3.91
33	4.232	3.989	3.91
32	4.432	4.313	4.21
15	4.701	4.485	4.31
34	4.726	4.485	4.31

Use the sliders or double click the value and use up/down arrow keys to change the fuel injection time and the spark advance. Your changes are applied in real time to the ECU so be careful. When you are happy with the results, press the Freeze button to apply either injection or advance changes. After the change has been permanently written the injection correction will return to 1.000 and the advance to 0.0.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Injection 1	0.010	6.359	6.359			1.000	Freeze
Injection 2	0.010	6.359	6.359			1.000	Freeze
Advance	0.5	6.0	6.0			0.0	Freeze

The Current and corrected windows give a real time readout of the existing ECU setting and the new setting, after the new settings have been written, both will be the same and the cell in the main window will be updated and showing in bold red to indicate that a change has been made

609	4.733	4.
852	5.746	5.
726	5.042	5

Now move onto the next cell you wish to work on. When all mapping work is done use the OFF button at top right. All of the modified cells are showing in bold red, including the ones in other pages.

If you want to make some manual changes at this stage you will need to exit the Map tuning page and use the Map edit page, this is easily done by pressing the Map button at the bottom of the page, the red bold cells are still showing and you are free to make manual changes.

This file must now be saved, use the Save button, choose Mapping and remember to remove the * prefix or you will not be allowed to save the file.

USB ▾	1098s			*1098s_v01				M197 v1.2								
Close	Tx	Rx	Config	Linear	Maps	Inj	Adv	Param	Save	Load	Monitor	Diag	Code	Pwd	Info	Exit

To finish the process, simply Transmit this map back to the ECU into either map 1 or map 2.

Maps / Page function overview

Enabled				Min.	Max.
TH2O / OIL	3.0	60.0	90.0		
Over-Rev	Margin RPM	150			
Cut-Off	Hold Time [ms]	0			
Cranking					
Transient					
OverTime					
Inj					

Save Load

Current Value				TJ Limit	
RPM	0	Lambda 1	0.0	Min.	1.000
Throttle	24.0	Lambda 2	0.0	Max.	32.000

Lambda	Set-Points	Current	Tolerance
12.5	12.5	12.5	0.0
Tracking Mode: Slow Fast			

For Help, press F1

RPM – value of engine RPM

Throttle – Value of Throttle sensor

Lambda – Current value of the lambda sensor in AFR

Lambda / Set point - Yours 3 desired targets AFR values

Lambda tolerance - +/- gate around your target AFR that is deemed to be acceptable. Once within this boundary to further Auto tuning would occur in Auto tune mode.

Tracking mode – In Auto tuning mode the engine must be latched into a cell for this amount of time before any correction will occur. You can choose between slow, medium, fast.

Enabled – This LED lights when the 'lambda searching phase' of the tuning strategy is permitted (not considering the enable setting of single cells). The lambda searching phase is inhibited during cranking, gear change, injection transients, engine cut-off, when the water temperature exceeds the given limits, or when the engine speed is near the limit set in the "Parameters" page..

Cranking – LED turns from brown to red during engine start. When active mapping will be inhibited.

Over rev – LED turns from brown to red when the engine is within 150RPM of the limiter.

Cut off – LED turns from brown to red when the 'cut off' strategy is enabled. When active mapping will be inhibited.

Transient - LED turns from brown to red when the transient strategy is active. When active mapping will be inhibited.

OverTime inj – LED turns from brown to red when injector are in over time

TH2O – Value of water temperature.

TH2O / Min-Max – Values of water temperature which are considered as normal for the operation of the engine, when outside of these limits the LED will turn red and mapping will be inhibited

TH2O	84.1	60.0	90.0
------	------	------	------

Tj limit – you set the minimum and maximum possible corrections from auto mapping

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777


Maps / Auto mapping

Before you begin mapping it is important to make sure that you have transmitted the latest version of your configuration and 'start map' into map slot 1. The ECU, the 'start map' is the one provided by your ECU supplier or one you believe to be closest to the one needed for this engine.

1. Make sure that your external map switch is in position 1 (open circuit)
2. Run the engine and check that all sensor readings are correct.
3. Warm up the engine until the water temperature value is within the correct zone
4. Ensure that there are no red LEDs showing
5. Enter values for your lambda and PI controls
6. Define the cells that you want the Auto tuning to take place in. You can choose between 3 different break point by a single, double or triple click in cell. Also you can choose an entire row or column.
7. Choose whether to map the injection on 'all cylinders' or an individual one
8. Use the left pull down to visualise the map you plan to work in.

It is very important when Auto tuning to specify which areas of the map this tuning should take place in. These cells can be defined by a double click in the map cell window to change colors, an example of this is shown here.

The end result can be saved and re-loaded at any time using these buttons.

A screenshot of the 'Maps (tuning)' window. It shows a grid of cells for mapping. The columns are labeled 'Injection 1' and 'RPM'. The rows are labeled 'RPM'. The cells contain numerical values. The window has tabs for 'Manual', 'Auto', and 'Off'. The 'Auto' tab is selected. The window also has a 'Save' button and a 'Load' button.

IMPORTANT – Auto mapping will only take place in a cell that has been activated in this way.


To begin Auto Tuning press the Auto button at the top of the page. The PC will now read back from the ECU the latest version of the injection and spark map. At the top of the page you will see a series of messages.

- Synchronising mapping data
- Loading injection data
- Loading advance data
- Lambda match or waiting for lambda (you are now ready to start)

You will notice that the file name you are now working with at the bottom of the screen is prefixed by a *, this is to indicate that the map has been taken from the ECU and not yet stored on your PC.



Adjust the engine using the dyno so that the throttle and RPM align with your chosen cell. Correct engine state will be indicated by the RPM and TPS values changing from yellow to red and the cell in the main window changing to grey as shown here.

A screenshot of the map cell window. It shows a grid of cells. The columns are labeled 'RPM' and the rows are labeled 'RPM'. The cells contain numerical values. The cell at row 15, column 32 is highlighted in grey.

Providing that all of the following conditions have been met, the ECU will begin to adjust the injection time to your target AFR. This will be seen in the main cell window by the text changing to red and the numbers moving. The manual sliders are inoperable during auto tuning.

- Cell must be activated for Auto Tuning
- Water temperature must be within limits
- No transient or start strategy active
- The engine is not in 'Cut off' or 'Over rev' status
- The engine has been locked onto the cell for at least the 'Hold time'
- The current lambda value must be outside of the target tolerance.

Once the target AFR has been achieved and the cell value stops changing, move onto the next cell and repeat

When all mapping work is done use the OFF button at top right. All of the modified cells are showing in bold red, including the ones in other cylinder pages

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Auto mapping - continued

If you want to make some manual changes at this stage you will need to exit the Map tuning page and use the Map edit page, this is easily done by pressing the Map button at the bottom of the page, the red bold cells are still showing and you are free to make manual changes.

This file must now be saved, use the Save button, choose Mapping and remember to remove the * prefix or you will not be allowed to save the file.



To finish the process, simply Transmit this map back to the ECU into either map 1 or map 2.

Maps / Auto mapping – Road tune

Before you begin mapping it is important to make sure that you have transmitted the latest version of your configuration and 'start map' into map slot 1.

1. Make sure that your external map switch is in position 1 (open circuit)
2. Run the engine and check that all sensor readings are correct.
3. Warm up the engine until the water temperature value is within the correct zone
4. Ensure that there are no red LEDs showing
5. Enter values for your lambda and PI controls
6. Define the cells that you want the Auto tuning to take place in (see below)
7. Choose whether to map the injection on 'all cylinders' or an individual one
8. Use the left pull down to visualise the map you plan to work in.

It is very important when Auto tuning to specify which areas of the map this tuning should take place in. These cells can be defined by a double click in the map cell window to change color, an example of this is shown here.

[ms]	0	1500	2100	3000	4000	5000	6000	6500	6750	7000	7250	7500	7750	8000	8250	8500	8750	9000
1.4	57	1.959	1.684	1.520	1.314	1.068	0.904	0.904	0.780	0.739	0.698	0.698	0.698	0.698	0.698	0.698	0.719	0.739
2.8	81	1.686	1.395	1.355	1.427	1.427	1.340	1.168	1.122	1.140	1.158	1.123	1.100	1.004	0.907	0.864	0.820	0.842
4.9	17	1.896	1.643	1.520	1.470	1.362	1.275	1.448	1.265	1.317	1.369	1.359	1.349	1.243	1.136	1.089	1.042	0.993
8.1	58	2.633	2.300	2.218	2.013	1.753	1.669	1.904	1.693	1.665	1.637	1.562	1.466	1.431	1.396	1.376	1.355	1.274
10.9	80	2.949	2.751	2.751	2.423	2.213	2.129	1.981	1.972	1.826	1.679	1.684	1.688	1.812	1.935	1.923	1.923	1.886
15.2	82	3.475	3.327	3.327	3.122	2.544	2.420	2.215	2.205	2.184	2.162	2.259	2.355	2.212	2.068	2.444	2.819	2.752
19.1	82	3.897	3.696	3.696	3.368	2.876	2.793	2.427	2.481	2.430	2.379	2.478	2.576	2.401	2.226	2.571	2.916	2.943
22.9	84	4.319	4.148	4.148	3.985	3.574	3.327	2.999	2.722	2.950	3.177	3.078	2.979	2.860	2.741	3.075	3.408	3.453
27.2	89	4.238	4.070	4.070	4.070	4.030	3.749	3.467	3.295	3.395	3.494	3.548	3.601	3.426	3.251	3.520	3.788	3.767
32.1	53	4.548	4.432	4.432	4.353	4.232	3.989	3.951	4.192	4.243	4.294	4.335	4.375	4.068	3.760	4.077	4.394	4.413
38.1	53	4.548	4.432	4.432	4.432	4.432	4.313	4.232	4.484	4.609	4.733	4.899	5.065	4.725	4.384	4.671	4.957	4.960
45.2	44	5.087	4.615	4.615	4.615	4.701	4.485	4.356	4.485	4.852	5.219	5.456	5.632	5.238	4.783	5.454	6.124	6.103
48.0	81	5.087	4.764	4.764	4.764	4.726	4.485	4.306	4.409	4.726	5.042	5.405	5.768	5.373	4.977	5.739	6.501	6.404
51.9	29	5.087	4.973	4.973	4.973	4.744	4.495	4.270	4.356	4.599	4.842	5.288	5.734	5.510	5.286	6.028	6.770	6.620
55.0	80	5.291	5.139	5.113	5.006	4.931	4.618	4.270	4.330	4.626	4.921	5.355	5.788	5.683	5.578	6.228	6.878	6.801
60.0	45	5.418	5.305	5.262	5.089	5.046	4.701	4.270	4.313	4.680	5.046	5.478	5.909	5.893	5.877	6.411	6.944	6.923
65.0	89	5.582	5.433	5.411	5.260	5.153	4.637	4.377	4.398	4.744	5.089	5.456	5.822	6.054	6.286	6.679	7.072	7.115
69.9	80	4.880	4.844	4.774	4.714	4.592	4.572	4.485	4.485	4.809	5.132	5.434	5.735	6.102	6.469	6.836	7.203	7.310
75.0	35	5.047	4.862	4.669	4.570	4.589	4.549	4.438	4.604	4.904	5.203	5.541	5.878	6.195	6.492	6.729	6.966	7.005
81.2	29	5.087	5.778	5.735	5.735	5.219	4.529	4.399	4.701	4.982	5.262	5.620	5.977	6.234	6.491	6.621	6.750	6.880

When using Auto tune modify your driving style so that there are no rapid changes of throttle, use of full power is fine, just get there progressively.

The end result of your selections can be saved and re-loaded at any time using these buttons. IMPORTANT – Auto mapping will only take place in a cell that has been activated in this way.



To begin Auto Tuning press the Auto button at the top of the page. The PC will now read back from the ECU the latest version of the injection and spark map. At the top of the page you will see a series of messages.



- Synchronising mapping data
- Loading injection data
- Loading advance data
- Lambda match or waiting for lambda (you are now ready to start)

Disconnect the serial lead from the ECU and begin your road tests, at no time should the map switch be changed or the power to the ECU switched off. If the power to the ECU is switched off the ECU will revert to the original map loaded into map 1. This last comment is also useful to note in the event that you have a failure of the lambda sensor and the corrections applied are not correct.

Auto tuning will occur when driving providing the following conditions are met

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

- Cell must be activated for Auto Tuning
- Water temperature must be within limits
- No transient strategy active
- The engine is not in 'Cut off' or 'Over rev' status
- The engine has been locked onto the cell for at least the 'Hold time'
- The current lambda value must be outside of the target tolerance.

It should be noted that all of the changes are not being written to the original maps 1 or 2, the

After the road test the ECU should be re-connected to the PC, at this point there are 2 possibilities:

- ECU has been switched off/on during the test
- ECU has remained switched on since it was disconnected from the PC.

Maps / Auto mapping – Road tune - continued

If the power to the ECU has **remained on** throughout the test the ECU will re-synchronise with the PC as soon as you re-connect and press the Open button. This is seen as a series of messages at the top of the screen.

- Synchronising mapping data
- Loading injection data
- Loading advance data

Once this sequence has completed any cells that have been modified in any cylinder will be visible as red bold text.


If you want to make some manual changes at this stage you will need to exit the Map tuning page and use the Map edit page, this is easily done by pressing the Map button at the bottom of the page, the red bold cells are still showing and you are free to make manual changes.

This file must now be saved, use the Save button, choose Mapping and remember to remove the * prefix or you will not be allowed to save the file.



To finish the process, simply Transmit this map back to the ECU into either map 1 or map 2.

If the power to the ECU has been **switched off** at any time during the test the ECU will give you the option to 'Load Tuning maps' as soon as you re-connect and press the Open button. This is seen as a pop up window. If you press **Yes**, the changes stored in the ECU will be visible as red bold text. If you press No, the changes are not uploaded.



If you want to make some manual changes at this stage you will need to exit the Map tuning page and use the Map edit page, this is easily done by pressing the Map button at the bottom of the page, the red bold cells are still showing and you are free to make manual changes.

This file must now be saved, use the Save button, choose Mapping and remember to remove the * prefix or you will not be allowed to save the file.




To finish the process, simply Transmit this map back to the ECU into either map 1 or map 2.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Inj

The **inj** page can be found by pressing this button



Maps / Edit / Injection (correction)

Air Temperature Correction																
[°C]	-20.0	-10.0	0.0	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	60.0	70.0	80.0
K	1.000	1.000	1.000	1.030	1.020	1.010	1.000	0.990	0.980	0.970	0.960	0.950	0.940	1.000	1.000	1.000

A gain can be applied to the fuelling at each of the individual temperature and pressure breakpoints. Gain of 1.000 = no correction. Gain of 0.000 will switch off the fuel at this temperature or pressure

Maps / Edit / Injection phase

Phase																
RPM	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
[deg]	110	110	110	110	110	110	110	110	110	110	110	110	110	110	110	110

Table for the definition of injection phase as a function of RPM – The angle is measured from Tooth 0 to the injection opening time. **FaseBase**.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Adv

The **adv** page can be found by pressing this button



Mon197 Professional v1.2b

Advance

Air Temperature Correction

[°C]	-10.0	-5.0	0.0	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	65.0
[deg]	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	-3.0	-4.0	-5.0	-5.0	-5.0

Water Temperature Correction

[°C]	-20.0	-10.0	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0	130.0
[deg]	5.0	5.0	5.0	5.0	4.0	4.0	3.0	3.0	1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Barometric Pressure Correction

[mBar]	400	450	500	550	600	650	700	750	800	850	900	1000	1050	1100	1150	1200
[deg]	6.0	5.0	5.0	5.0	4.0	4.0	3.0	3.0	2.0	2.0	1.0	0.0	0.0	0.0	0.0	0.0

Cyl. 1 RPM

[deg]	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	9000
10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
60.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
70.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Cyl. 2 RPM

[deg]	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	9000
10.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
60.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
70.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

USB 1098s_fw102 1098s_fw102_SP_SO_v01 M197 v1.2

Close Tx Rx Config Linear Maps Inj Adv Param Save Load Monitor Diag Code Pwd Info Exit

Maps / Edit / Advance (correction)

Air Temperature Correction																
[°C]	-10.0	-5.0	0.0	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	65.0
[deg]	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	-2.0	-3.0	-4.0	-5.0	-5.0	-5.0

An offset in Deg can be applied to the advance at each of the individual temperature and pressure breakpoints.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Param

The **param** page can be found by pressing this button



Start & On/Off

Fuel-Pump Timer [ms]	3000
Pre-Injection Delay [ms]	250
Drop-Switch Delay [ms]	100

Engine Thresholds [rpm]

Upper (ON)	100
Lower (OFF)	50

Pre-Injection Time

[°C]	-10.0	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0	130.0	140.0
[ms]	22.0	22.0	18.0	17.0	16.0	14.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0

Cut-Off

Speed [rpm]	15000
Throttle [deg]	0.0
Exit Time [ms]	0

Shift Light [rpm]

Light 1	10000
Light 2	11000

Engine Speed Limits [rpm]

Spark	Injection
11700	11500
User correction [rpm]	0

Corrections

Advance [deg]	Cyl. 1	Cyl. 2
K-Injection	1.000	1.000

Set-Points Idling

	Low	High
Water/Oil T. [°C]	50.0	70.0
Idling [rpm]	1800	1350
User correction [rpm]	0	
Delta Idling [rpm]	400	
Ramp Idling [ms]	400	
Idling Start [%]	100.0	
Min Farf [deg]	6.0	

Gear

Shift Sequence	
MinSpeed [rpm]	3000
Delay [ms]	5
TimeOut [ms]	60
HoldOff [ms]	300
K-Injection	1.000

Wheels

Circumference [mm]	2020
Pulses	4

Fan Control

1 - Water/Oil T [°C]	95.0
----------------------	------

CO-correction

OFF

Reset

Activation Limits	Inf.	Sup.
Speed [rpm]	200	4000
Throttle [deg]	0.0	70.0
Water/Oil T [°C]	60.0	95.0

Inj. Correction [%]

Step	Max.
0.1	30.0

Time Base [sec]

0.1

In this section you can make changes to some preloaded parameters.

Maps / Edit / Parameters / Start – Turn on/off

Start & On/Off

Fuel-Pump Timer [ms]	3000
Pre-Injection Delay [ms]	250
Drop-Switch Delay [ms]	100

Engine Thresholds [rpm]

Upper (ON)	100
Lower (OFF)	50

Pre-Injection Time

[°C]	-10.0	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0	130.0	140.0
[ms]	22.0	22.0	18.0	17.0	16.0	14.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0

Fuel pump timer – value in Ms for the fuel pump to run at ‘power on’

Pre-Injection delay - Amount of time after power on before the injectors open for the single pre-injection.

Drop switch delay time – Delay after the Dropswitch input is activated before the engine cut occurs, this is to ensure that small events less than this time do not interfere with normal operation.

Engine threshold – ON/OFF - RPM boundaries to define when the engine is running and when it has stopped. Always ensure that the Lower is less than the Upper and provide spacing between these parameters to create a hysteresis.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Pre injection time – At ECU power on all injectors are opened for a short period of time to prime the cylinders. The duration of this opening is defined within the **Pre-injection Time** table as a function of water temperature.

Maps / Edit / Parameters / Start – Cut-off

Cut-Off			
Thresholds		Corrections	
Speed [rpm]	15000	Advance [deg]	0.0
Throttle [deg]	0.0	K-Injection	1.000
Exit Time [ms]	0		

The 'cut off' parameters are used for controlling spark advance and fuelling during engine 'over-run'.

To enable this strategy the engine must have a higher

RPM than the **Threshold – Speed** and lower throttle value than the **Threshold – Throttle**.

Throttle variation – limit to disable special strategy in function of throttle variation

Throttle var. Filter Depth – number of sample to calculate throttle variation

Special Exit Duration Count – number of revolutions to get the maximum out of the special strategy

When the strategy is active the correction settings for Advance as an 'additive' and Injection time as a Gain are applied to the map for each cylinder. Note that a gain of 0 to the injection time will cut the fuel completely.

When the strategy de-activates you can specify an **exit time** to return to normal map settings.

Shift light [rpm]: thresholds to enable dashboard led for rpm out of range.

Engine speed limits [rpm] – user [rpm]: you can change the limiter bike for injection and ignition.

Set-Points Idling		
	Low	High
Water/Oil T. [°C]	50.0	70.0
Idling [rpm]	1800	1350
User correction [rpm]	0	
Delta Idling [rpm]	400	
Ramp Idling [ms]	400	
Idling Start [%]	100.0	
Min Farf [deg]	6.0	

Set points idling parameters about minimum valve control.

Water/oil T – idling rpm: depending on the temperature, the minimum can be set to two different values.

Delta idling – action threshold of the strategy of minimum.

Ramp idling – time necessary to eliminate the gap between delta and minimum.

Idling Start – valve position at ECU power on

Min farf – opening throttle threshold above which disables the control of the minimum.

Shift Light [rpm]	
Light 1	10000
Light 2	11000
Engine Speed Limits [rpm]	
Spark	Injection
11700	11500
User correction [rpm]	-500

Min Speed – Minimum RPM for the gear shift sequence to activate.

Delay – Delay in Ms for the strategy to activate following either a signal from the Load cell, the Switch input or the Shift threshold from the potentiometer.

Time out – The maximum time for the gear change process to complete in Ms.

Hold Off – To eliminate the possibility of a 'double switch' the time 'de-bounce' disables the strategy from re-occurring for 'x' Ms starting from the end of the previous occurrence.

Advance – Spark advance value to be applied during gear change, this value replaces the main map.

K- Injection – Correction factor applied to the main Injection map for the duration of the gear change.

Wheels	
Circumference [mm]	2020
Pulses	4

These parameters are used to calibrate the front and rear wheels speeds. Enter the rolling circumference in mm and the number of trigger teeth for one wheel revolution.

Gear	
Shift Sequence	
MinSpeed [rpm]	3000
Delay [ms]	5
TimeOut [ms]	60
HoldOff [ms]	300
K-Injection	1.000

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Remember that this needs to be correct if you are planning to use wheel speed within your map corrections.
CO correction

CO-correction

<div>ON</div> <div>Reset</div>	Activation Limits		Inf.	Sup.		Step	Max.
	Speed [rpm]	200	4000		Inj. Correction [%]	0.1	30.0
	Throttle [deg]	0.0	70.0				
	Water/Oil T [°C]	60.0	95.0		Time Base [sec]	0.1	

On-Off - button to enable CO correction

Reset – button for reset map inside the ECU about CO correction

Speed [rpm] – engine speed threshold within is on CO correction

Throttle [deg] – throttle threshold within is on CO correction

Water/oil T [°C] – temperature threshold within is on CO correction

Inj correction [%] – minimum step variation of the injection from the correction, and maximum total allowable variation

Time base – repetition frequency of the strategy CO correction.

Maps / Edit / Parameters / Page 2 / Transient

The **param** page can be found by pressing this button

USB	1098s	1098s_v01	M197 v1.2													
Close	Tx	Rx	Config	Linear	Maps	Inj	Adv	Param	Save	Load	Monitor	Diag	Code	Pwd	Info	Exit

You can change from page 1 and 2 through a sequence pressure of param button. Page 2 of parameters contains the corrections of the strategy of transient for injection and ignition.

Mon197 Professional v1.2b

Parameters (pag 2/2)

Advance Transient

Time Base [ms]	5	+	Thresholds [deg]	1 (lower)	2	3	4	5	6	7	8 (upper)
Filter Depth	5		Gain	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
Noise Threshold [deg]	1.0		Decay [deg/ms]	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Clipping [deg]	+ 5.0	-	Thresholds [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	- 5.0		Gain	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
			Decay [deg/ms]	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

Coefficient by RPM

[rpm]	900	1000	1100	1200	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500
KA+	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000
KA-	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000

Injection Transient

Time Base [ms]	5	+	Threshold [deg]	1 (lower)	2	3	4	5	6	7	8 (upper)
Filter Depth	5		Gain	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
Noise Threshold [deg]	1.0		Decay [deg/ms]	0.500	0.500	0.500	0.500	0.500	0.500	0.500	0.500
Clipping [ms]	+ 5.000	-	Threshold [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	- 1.500		Gain	0.70	0.70	0.50	0.50	0.20	0.00	0.00	0.00
			Decay [deg/ms]	0.500	0.500	0.500	0.500	0.500	0.500	0.500	0.500

Coefficient by RPM

[rpm]	900	1000	1100	1200	1250	1500	1750	2000	2250	2500	2750	3000	3250	3500	3750	4000	4250	4500
KJ+	3.500	3.500	4.000	4.000	4.000	4.500	5.000	5.500	6.000	6.500	7.000	6.750	6.500	6.000	5.750	5.000	4.750	3.500
KJ-	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000

Coefficient by Water/Oil Temperature

[°C]	-20.0	-10.0	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0	130.0
KJ+	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
KJ-	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

USB	1098s_fw102	1098s_fw102_SP_SO_v01	M197 v1.2													
Close	Tx	Rx	Config	Linear	Maps	Inj	Adv	Param	Save	Load	Monitor	Diag	Code	Pwd	Info	Exit

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
 Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Edit / Parameters / Page 2 / Advance Transient settings 1.

The transition of the advance is given by the following parameters:

Time base (ms). – gives the time which is updated the calculation of transient.

Filter depth – number of samples which filter the input.

Noise threshold – Threshold for the noise variations in the input signal.

The following parameters are split to separate the calculation in function of the throttle input (+ , -)

Clipping – maximum (+) and minimum (-) value in degree of advance are allowed for final results of a transitional strategy.

Advance Transient	
Time Base [ms]	5
Filter Depth	5
Noise Threshold [deg]	1.0
Clipping [deg]	+ 5.0
	- 5.0

Maps / Edit / Parameters / Page 2 / Advance Transient settings 2.

To enable differing transient values at different throttle values, 8 breakpoints for may be defined in the upper row.

Within these throttle boundaries the rate of change of throttle is

monitored as per previous settings and a positive **Gain** is applied to suit your needs. This output is known as the **Throttle Advance transient** and will be a value either Positive or Negative depending whether the throttle was opening or closing. For all of the Positive transient states the upper set of values will be applied.

		1 (lower)	2	3	4	5	6	7	8 (upper)
+	Threshold [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	Gain	1.30	1.30	1.30	1.30	1.30	1.30	1.30	
	Decay [deg/ms]	1.000	1.000	1.000	1.000	1.000	1.000	1.000	
-	Threshold [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	Gain	0.40	0.40	0.40	0.40	0.40	0.40	0.40	
	Decay [deg/ms]	1.000	1.000	1.000	1.000	1.000	1.000	1.000	

Decay (deg/ms) – Maximum transient decay (decreases for positive values) allowed in a single time interval (as defined by the Time Base). This applies starting from the time the transients begins to decrease until it returns to 0. The effect is to limit the speed of the transient's decay (return to normal)

Similar settings are applied when the throttle is reducing.

The injection time transient can be further modified by applying Gains as a function of different RPMs **DJDInTrpm** as shown in this table below.

Coefficient by RPM																			
[rpm]		900	1150	1800	2700	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	8500	9000	9500
KA+		1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000
KA-		-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000	-1.000

The KA+ is used to modify positive (increasing) throttle transients and the KA- is used to modify negative (reducing) throttle transients.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Maps / Edit / Parameters / Page 2 / Injection Transient settings 1

The Injection transient is defined by a series of parameters.

Time base Ms. – Time period over which the input change is considered.

Filter depth – Number of samples over which the filter is calculated.

Noise threshold – Value in throttle deg / mBar variation within which the transients are not considered. This is used to eliminate small fluctuations in throttle / Air pressure stability.

The choice of **mBar** or **Throttle** is defined with the Configuration page as detailed in section 1.17

Clipping – Maximum (+) and Minimum (-) value in mSec injector duration that are permitted as a result of the transient strategy.

Injection Transient	
Time Base [ms]	5
Filter Depth	5
Noise Threshold [mBar]	1
Clipping [ms]	+ 0.900
	- 0.500

Maps / Edit 8.4 / Parameters / Page 2 / Injection Transient settings 2

To enable differing transient values at different throttle values / Air pressures, 8 breakpoints for may be defined in the upper row.

Within these boundaries the rate of change of

Throttle / Air pressure is monitored as per previous settings in 8.4 and a positive **Gain** is applied to suit your needs. This output is known as the **Injection time transient** and will be a value either Positive or Negative depending whether the throttle was opening or closing. For all of the Positive transient states the upper set of values will be applied.

		1 (lower)	2	3	4	5	6	7	8 (upper)
+	Threshold [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	Gain	1.30	1.30	1.30	1.30	1.30	1.30	1.30	
	Decay [deg/ms]	1.000	1.000	1.000	1.000	1.000	1.000	1.000	
-	Threshold [deg]	0.0	10.0	20.0	30.0	40.0	50.0	70.0	100.0
	Gain	0.40	0.40	0.40	0.40	0.40	0.40	0.40	
	Decay [deg/ms]	1.000	1.000	1.000	1.000	1.000	1.000	1.000	

Decay (deg/ms) – Maximum transient decay (decreases for positive values) allowed in a single time interval (as defined by the Time Base). This applies starting from the time the transients begins to decrease until it returns to 0. The effect is to limit the speed of the transient's decay (return to normal)

Similar settings are applied when the throttle is reducing.

The injection time transient can be further modified by applying Gains as a function of different RPMs **DJDlnTrpm** as shown in this table below.

Coefficient by RPM																			
[rpm]	900	1000	1150	1300	1500	1600	1800	2200	2400	2600	2800	3000	3200	3500	3800	4000	4200	4600	
KJ+	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.500	1.500	1.300	1.300	1.300	1.300	1.500	1.200	1.200	
KJ-	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	-0.500	-1.000	-1.000	-1.000	-1.000	-1.000	

It may also be adjusted by applying gains as a function of water temperature - **DJDlnTth2o**


Coefficient by Water Temperature																
[°C]	-10.0	0.0	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0	130.0	140.0
KJ+	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
KJ-	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Monitor

The **monitor** page can be found by pressing this button



This page is used for the following purposes:

- Real-time monitoring of the inputs, outputs, internal values of the calculations.
- Alarm signals.
- Manual check for fuel pump, injectors and trigger.
- Reading of the files in the unit.

Engine

RPM – Real time read out of the engine speed. The larger green LED to the left only illuminates when the crank/(cam) pattern is recognised and considered by the ECU to be correct. The smaller LED turns red if the drop switch or kill switch inputs are active.

Revolutions – Total number of engine revolutions since the engine started, each time the motor stops/starts this count is reset.

Smot / err – (Smot = Speed Motor) Total number of signals seen from the crank sensor with an error count of the number of signals that are considered to be out of sequence. Count is re-set at engine stop/start

Injection – This LED is activated when the fuel injectors are in operation.

Cranking – This LED is activated during the cranking phase of the engine start.

Spark – This LED is activated when the ignition coils are in operation.

Fan – Heat – Coc – These LED are activated when are on respectively fan, heat, CO correction

Cut Off – This LED is activated when the engine is in 'Cut Off' state

Over Dwell – One or more of these LEDs will illuminate if the ignition coil charge time is too long. Number equates to the cylinder number.

Injection over time – One or more of these LEDs will illuminate if the injection time is too long. The upper row is for high bank injectors, the lower row for the primary bank. Number equates to the cylinder number.



MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Analog inputs

Throttle – value indicates the percentage of gas

Water Temp – in degrees celsius indicates the water temperature or oil depending on the Ducati model.

Air Temp – in degrees celsius indicates the air temperature

Barometric P. – in millibar indicates the barometric pressure

Narrow band 1,2 – indicates air-fuel ratio

Battery – in volt indicates the battery voltage

Fuel level – indicates the level in liters of petrol

Lambda 1,2 – indicates air-fuel ratio of analogue lambda

Map select – indicates how map is active

Adv/Inj transient – Values of the transient are not genuine channels but an indication of the transient state.

Oil P. [LOW] – indicates with a red led when there isn't pressure oil in the engine

Analog Inputs		Cnt
Throttle	24.0	273
Water Temp.	3.0	969
Air Temperature	-40.0	954
Barometric P.	150	15
Narrow-Band 1	15.3	128
Narrow-Band 2	0.0	50
Battery	11.7	564
Fuel Level	0.0	15
Lambda 1	0.0	
Lambda 2	0.0	
Map-Select	1	
Adv.Transient	0.0	
Inj. Transient	0.0	
Oil P. [LOW]		

Wheels

Velocity – indicates in km/h the current speed of the vehicle

Space – indicates the space from the last power on of the unit.

Wheels	
Velocity	0
Space	0.0

Injection Components

This section is dedicated to the values and corrections that make up the Injection time.

TerogBase 1,2 – Base injection time at the current map position in Ms of duration.

KJUser 1,2 – Gain correction applied as individual cylinder correction.

KJTH20 – Correction gain as a function of water temperature

KJTAir - Correction gain as a function of air temperature

KJCrank - Correction as a function of cranking and cold start map

KJVel - Correction as a function of speed

KJPbaro - Correction as a function of the barometric pressure

DJDInjTrpm – Correction additive in Ms generated by the transient strategy as a function of RPM.

DJDInjTh2o – Correction additive in Ms generated by the transient strategy as a function of water temperature.

DJDInt – Total correction additive in Ms generated by the transient strategy including the 'clipping'

OffsVbataux – Additive correction to the injection time as a function of the battery voltage – High bank

OffsVbat – Additive correction to the injection time as a function of the battery voltage – Low bank

Injection Components			
TerogBase 1	6.359	TerogBase 2	6.359
KJUser 1	1.000	KJUser 2	1.000
KJTH20/OIL	1.489	DJDInjTrpm	0.000
KJTAir	1.000	DJDInjTh2o	0.000
KJCrank	1.000	DJDInt	0.000
KJVel	1.000	OffsVbat	0.479
KJPbaro	1.000	OffsVbatAux	0.479

Advance Components

This section is dedicated to the values and corrections that make up the ignition advance. All values are in degrees of crank angle

TetaBase - Base Ignition advance taken from the map at the current breakpoint position.

KATH20 – Correction as a function of water temperature

KATAir - Correction as a function of air temperature

KAPair - Correction as a function of air pressure

KAVel - Correction as a function of speed

KAUser - Correction as a function of individual cylinder settings.

DADint – Correction as a function of the Advance transient strategy

DAPickUp - Correction as a function of the PickUp table

Advance Components			
KAUser 1	0.0	KAUser 2	0.0
TetaBase	6.0	KATH20/OIL	5.0
KATAir	0.0	KAVel	0.0
KAPbaro	6.0	DADInt	0.0
		PickUpTable	0.0

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

This section displays the final values of injection, advance, phase, dwell time of each cylinder.

	Cyl. 1	Cyl. 2
Terog	9.957	9.957
Terog Aux.	0.000	0.000
Phase	110.0	110.0
Advance	17.0	17.0
Dwell	2.421	2.421

Digital I/Os

Green LED indicates activation of digital input or output.

By using the fuel pump button can run for a few seconds the fuel pump.

Gear

Green LED indicates the activation of a part of the strategy for change

Gear			
Set	<input type="checkbox"/>	Time-Out	<input type="checkbox"/>
Shift	<input type="checkbox"/>	Cut-Off	<input type="checkbox"/>
Hold-Off	<input type="checkbox"/>		

Outputs Test

These buttons are used to activate manually the trigger output and the injectors to test the electrical circuit. These manual tests must be done before starting the engine for the first time to ensure proper function. Some buttons are not highlighted for use. This depends on the configuration of the system.

Outputs Test			
Cyl.1	Trig	Inj	Inj Aux
Cyl.2	Trig	Inj	Inj Aux
Bike type			
Superbike 1098			

Bike type

Indicates the type of model Ducati selected

This section displays the names of the files uploaded to the unit. In the mode show in the picture is on map 1

Mapping Data 1	_default
Mapping Data 2	_default
Configuration	1098s

Password

USB	1098s			1098s_v01		M197 v1.2							
Close	Tx	Rx	Config	Correction	Param	Save	Load	Monitor	Diag	Code	Pwd	Info	Exit

The password is a means of protecting your maps and configurations from other subsequent users of the ECU.

When the protection is active it is not possible to transmit or receive either the configuration or mapping data between ECU and PC, map-tuning is also inhibited.

All internally calculated values related to engine control for ignition and injection plus some others are hidden, and the protection state of the ECU is signalled by the text colour in the **Open/Close** push-button (red = protected; green = unprotected; black = not connected).

Pressing the **PWD** button opens the Protection dialog-box. You can enter a password at any time, even when the connection between ECU and monitor is not active. After typing the password press the **Log in**

Protection

Enter password:

Log in

Change

Cancel

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

button to confirm it. When the connection to an ECU is established, the password is repeatedly sent to the ECU which evaluates if it is correct by comparing it with the copy stored in memory, the protection state is set accordingly.

You can modify the internally stored password when connection is active. In this case, after entering the new password, you have to press the **Change** button, then re-enter the password and press the **Confirm** button. **IMPORTANT** -Be aware that changing the ECU's internal password will erase all configuration and mapping data (after a final confirmation by the user)

Diag

The **Diag** page can be found by pressing this button



The diagnostic page is important because it records everything that happens while the bike is running.

Mileage, hour meter, maximum engine revolutions. (**Engine e engine user**)

Also making a count of activation of the input (**Input count**)

There is also a counting about **over dwell** of coil, **over time** of injector and errors reading of **narrow band** (CO correction)

Through "**reset error and count**" button you can reset all the counters errors.

The section Engine password allows to enable the reset pf the engine, but be aware of the keyword to be insert in the white cell.

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

By default all of these diagnostics are turned off, to activate them place a tick on the **On** box. Note: You will need an active link with the ECU to achieve this as the parameters are stored directly into the ECU EEPROM

Each line of this section is split up into the following sections:

Total errors – Count of the number of times this input has gone outside of your Min / Max values

Reset – Resets the error count to 0

On – Turns on the diagnostic for this input

Max consecutive errors – Maximum number of error count before the ECU considers this input to be unreliable and uses the Recovery value

Min value – Minimum sensor value in 10bit A/D, the figure on the right automatically shows you the value in engineering units based on your input elaborations.

Max value – Maximum sensor value in 10bit A/D, the figure on the right automatically shows you the value in engineering units based on your input elaborations.

Recovery value – value used by the ECU if the error count exceeds the limits you have specified in 'max consecutive errors'. Enter a value in 10bit A/D format, the figure on the right automatically shows you the value in engineering units based on your input elaborations.



Analog	Total Errors	Reset	On	Max. Consec. Errors	Min. Value	Max. Value	Recovery Value			
Throttle	0	Reset	<input checked="" type="checkbox"/>	100	0	2.5	1023	86.0	512	43.8
Oil Temp.	0	Reset	<input type="checkbox"/>	65535	0	125.0	1023	-20.0	512	73.5
Fuel Level	0	Reset	<input type="checkbox"/>	65535	0	0.0	1023	0.0	512	0.0
Battery	0	Reset	<input type="checkbox"/>	65535	0	0.6	1023	20.8	512	10.7

MICROTEC S.r.l.

Via Avvis 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777

Code

The **Code** page can be found by pressing this button



On this page you can enter code sto unlock some additional function software. The serial number shown is essential for tracing the correct codes.

Enter the code in the white cell and then click insert code.
If you see green LED like this picture, everything is successful.

Installation / Electrical connections

PIN	Function	Note
AUX 1	CODELOAD	Input program mode
AUX 2	CAN1H	Communication CAN line"H" CAN2
AUX_3	CAN1L	Communication CAN line "L" CAN2
AUX 4	PGND	Power ground
AUX 5	DROPSW	IInput tilt sensor (drop)
AUX 6	UEGO	Input sensor lambda UEGO
AUX 7	VBAT	12V Battery
AUX 8	SGND	Analog ground

END

MICROTEC S.r.l.

Via Avris 3 – 21032 CARAVATE (VA) ITALY – C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA
Tel. +39 0332 601731 – Fax +39 0332 771777