

**MICROTEC S.r.l.**

Sede Legale Via Avvis 3/A – 21032 CARAVATE (VA) ITALY  
P.IVA 02356120127 – C.F. 02356120127  
Tel. +39 0332 601731 – Fax +39 0332 771777  
Capitale Sociale € 10.200 i.v Reg. Imprese di Varese n. 02356120127  
REA n. 251455

[www.microtec.cc](http://www.microtec.cc)

**MICROTEC®**

## Map description – Hypermotard 1100

---

### ***Configuration file - ECD***

Map configuration file name (*.ecd)	HM_1100_stdCfg
For use with	M197
ECU firmware version	1.3
ECU hardware build version	1.00.2
Created by	Microtec S.r.l.

### ***Mapping file - EMD***

Map file name (*.emd)	HM_1100_baseMap
For use with	M197
ECU firmware version	1.3
ECU hardware build version	1.00.2
Created by	Microtec S.r.l.
Spark map	Standard DP
Fuel map	Standard DP
RPM limit – spark cut	8900
RPM limit – fuel cut	8700
Tyre circumference	2.070m
Wheel triggers	4

### ***Notes:***

- Developed for use with standard exhaust + slip ons
- Standard exhaust – Exhaust valve may remain in place but will stay permanently open.